

Wall & Floor Anchors

(Used if the lift is against a dock, raised platform, or sill)

First secure anchors to the wall and floor as shown below, then push lift into place and insert longer bolt through the anchors to secure the frame of the lift against the wall. Each anchor is secured by six 5/8" anchor bolts, which will be included with the lift.



Wall and floor anchors hold the lift in place by securing the front cross-member against the wall.

This bolt can be removed whenever the lift needs to be moved out of the way or temporarily used elsewhere.



For installation questions, feel free to contact Superior Handling Equipment at (800) 221-4339.